



NOTES: IF STYROFOAM INSULATION IS INSTALLED, HYDRODRAIN IS TO BE PLACED ON TOP OF STYROFOAM.

NUMBER OF STOPS AND NUMBER AND LENGTH OF REQUIRED TENDONS (MAY NOT BE FULL LENGTH) IS DETERMINED BY MEDIA DEPTH AND DEGREE & LENGTH OF SLOPE.

TOP OF SLOPE ATTACHMENT PULL OUT STRENGTH AND METHOD OF ATTACHMENT MUST BE DETERMINED AND VERIFIED BY PROJECT ENGINEER

AMERICAN HYDROTECH, INC. DOES NOT ASSUME THE ROLE OF AN ARCHITECT AND/OR ENGINEER FOR ANY INSTALLATION. THESE DETAILS SHOULD BE VERIFIED BY AN ARCHITECT, ENGINEER OR OTHER PROFESSIONAL, CHARGED BY THE OWNER, AS TO THERE SUITABILITY AND APPLICABILITY FOR THERE INTENDED USE.



**GARDEN
ROOF
ASSEMBLY**

AMERICAN HYDROTECH, INC.

GARDNET WING TENDONS
AND SPACERS

NO SCALE

GR-10